TABLE 1. List of Software Commands(Continued)

Req	Command Type	Command	Reference Page
1-35		Add Bad Continuous Clocking Column	page 104
1-36		Reset Bad Continuous Clocking Column Map	page 104
1-37		Dump Bad Continuous Clocking Columns	page 103
1-38		Add Bad Timed Exposure Column	page 104
1-39		Reset Bad Timed Exposure Column Map	page 104
1-40		Dump Bad Timed Exposure Columns	page 103
1-41			
1-42	Uplink Boot Commands		page 129
1-43		Start Load from Uplink	page 129
1-44		Continue Load from Uplink	page 129
1-45			
1-46	Patch Commands		page 125
1-47		Add Patch	page 126
1-48		Remove Patch	page 126
1-49		Dump Patch List	page 127

TABLE 1. List of Software Commands

Req	Command Type	Command	Reference Page
1-1	Parameter Block Commands		page 40
1-2		Load Timed Exposure Parameter Block	page 53
1-3		Load Continuous Clocking Parameter Block	page 81
1-4		Load DEA Housekeeping Parameter Block	page 122
1-5		Load 2-D Window List	page 57
1-6		Load 1-D Window List	page 84
1-7			
1-8	Science Control Commands		page 40
1-9		Stop Science Run	page 44
1-10		Start Timed Exposure Run	page 48
1-11		Compute Timed Exposure Bias	page 48
1-12		Start Continuous Clocking Run	page 80
1-13		Compute Continuous Clocking Bias	page 80
1-14			
1-15	DEA Housekeeping Control Commands		page 122
1-16		Start DEA Housekeeping Run	page 123
1-17		Stop DEA Housekeeping Run	page 123
1-18			
1-19	Memory Commands		page 106
1-20		Read BEP Memory	page 107
1-21		Write BEP Memory	page 108
1-22		Execute BEP Memory	page 109
1-23		Read FEP Memory	page 110
1-24		Write FEP Memory	page 108
1-25		Execute FEP Memory	page 109
1-26		Read SRAM	page 109
1-27		Write SRAM	page 108
1-28		Read PRAM	page 109
1-29		Write PRAM	page 108
1-30	System Configuration Commands		page 99
1-31		Change System Configuration Setting	page 101
1-32		Add Bad Pixel	page 102
1-33		Reset Bad Pixel List	page 102
1-34		Dump Bad Pixels	page 103