TABLE 1. 'Parameter Block' Operations

Function	Inputs	Outputs
Initialize	none	Marks the block as "unused"
Get Block Id	none	Returns the "block id" of the Parameter Block
Check CRC	none	Computes the block's CRC and compares it with the stored CRC. If the values are different, this function returns an error.
Get Length	none	The length of the parameter block
Get Parameter Block Identifier	none	The Parameter Block Identifier used by the ground to associate the block with the resulting science data.
Copy to Buffer	Address of destination buffer.	Fills the specified destination buffer with the contents of the parameter block's data. The copied data has the same format as the data portion of the Command Packet used to load the block.
Load from Command Packet	Address of Command Packet containing the new block contents	none