TABLE 1. 'Parameter Block List' Operations

Function	Inputs	Outputs
Initialize	none	Re-loads ROM blocks and marks remaining blocks as "unused"
Check Blocks	none	Computes the CRC of all used blocks and flags any which have been corrupted.
Replace Block	Command Packet containing Parameter Block id and contents	Overwrites a block with the new parameters specified in the Command Packet.
Get Block	Block Id	Address of the parameter block, or an error code if the block is unused or has an invalid CRC.