Address	(msb) 7	6	5	4	3	2	1	(lsb) 0
0x10000	100KHz Sequencer Offset (0..63)						Stop Sequencer	Start Sequencer
0x10001	100KHz Video ADC Offset (0..63)						Stop Video ADC	Start Video ADC
0x10002	-	Hold House-keeping Address	-	-	Video Output Enable Channel D	Video Output Enable Channel C	Video Output Enable Channel B	Video Output Enable Channel A
0x10003	-	-	-	Status Enable (active low)	High Speed Tap Enable (active low)	Clock Swap Enable	Back Junction Diode Enable	-