TABLE 1. 'PRAM Synthesizer' Operations

Function	Inputs	Outputs
Initialize	none	none
Generate	CCD List Clocking Parameters to use	Generates a PRAM sequence given the specified parameters, and loads the sequence into the DEA subsections associated with the specified CCDs.
Check	CCD List Clocking Parameters to use	Generates a PRAM sequence given the specified parameters, and compares the sequence with that loaded in the DEA subsections associated with the specified CCDs.