TABLE 1. Command Echo Telemetry Content

Req	Item	Description
1-1	Packet Synch	This field marks the start of the ACIS packet within the telemetry stream.
1-2	Packet Word Length	This field indicates the number of 32-bit words in the packet.
1-3	Format Tag	This field indicates the type of data contained in the telemetry packet.
1-4	Packet Sequence Number	This field is used to sequentially number all ACIS telemetry packets.
1-5	BEP Tick Counter	This item contains the value of the internal timer-tick counter at approximately the time at which the command packet was received by the software.
1-6	Command Result Code	This is the disposition code of the command. These codes shall be capable of representing the following types of conditions:
		Command executed successfully without warnings or errors
		Command was not executed (code must indicate reason)
		Command executed with warnings (code must indicate reason)
		Command executed with errors (code must indicate reason)
1-7	Copy of Command Packet	This is a copy of the command packet received by the ACIS software